


Operating Instructions For ABO Dual Plate Check Valves, Series 700

1. Introduction
2. Safety Instructions
3. Valve Identification
4. Transportation and Storage
5. Installation into Pipes
6. Pipe Pressure Test
7. Operation and Maintenance
8. Troubleshooting
9. Other Informations





1. Introduction

ABO dual plate check valves series 700 are used to prevent return flow in the pipe. The correct type and material design is determined using brochures and material data sheets, or consultations with the manufacturer.

2. Safety Instructions

Installation, operation and maintenance may only be performed by properly trained and instructed staff. For detailed safety regulations see the separate document, which must be read carefully before installation.

3. Valve Identification

ABO dual plate check valves are designed for clean and polluted water, waste water and viscous liquids. The DN and PN are marked on the valve body. The body is also marked with the direction of flow. Each valve is labelled with a plate specifying PS (bar), TS (°C) and materials of the body, disc, shafts and gaskets.

4. Transportation and Storage

The valves are transported and stored in the packaging from the manufacturer. The valves must be stored indoors in dry and dust-free environment at normal temperatures.

5. Installation into Pipes

The procedure is graphically described in the document Installation Instructions. Gaskets are inserted between the valve body and flanges; it is therefore necessary to use flanges with flat sealing strips, e.g. B shape according to EN 1092.

Before installation it is necessary to examine

- Whether the PN, DN and materials of the supplied valve correspond to the intended use,
- Whether damage occurred during transportation. Do not use damaged valves!
- Check the correct function of the valve (full opening and closing).
- Counter-flanges must be aligned and parallel; any impurities and solid particles from the flanges and piping must be removed.

The arrow on the body marks the direction of the flow.

The flanges may not be welded on an installed valve!

6. Pipe Pressure Test

The valve is pressurized by the manufacturer. When fitted in the pipeline the entire pipe section with valves needs to be pressurized. The following must be observed:

- newly installed section must be carefully rinsed (in the direction indicated by the arrow on the valve) and cleaned to remove any mechanical impurities,
- pressurise in the direction of the arrow to 1.5 times the PN.

7. Operation and Maintenance

Non-return valves work automatically and are maintenance free. They must be monitored during operation for leaks, corrosion, etc.

8. Troubleshooting.

In case of failure and repair it is necessary to observe all safety rules – see the separate document Safety Regulations.

Failure	Measure
Leakage between the valve and flange	Tighten the flange bolts. In the case of ongoing leakage, replace the sealing between the valve and flange.
Closure leakage	Send the valve to the manufacturer.